

Installation of Electrical Wiring

Essentially, the possible methods include drilling through the wall from top to bottom with a long, approximately 16mm drill bit, row by row during installation.

The picture below shows the lower wall details which are pre-drilled at the locations marked with red arrows, four rows high.

Alternatively, you can run conduit externally and drill directly through the wall.

We also suggest an external distribution board to maintain the internal aesthetics.



