

Window and door waterproofing instructions WP 1

For window and door waterproofing we suggest to use outside UV proof silicone + wind/water protection tapes.

There are plenty of different tapes in building material stores available, ask shop attendant.

For lower horizontal and side vertical gaps we suggest max 50mm wide tapes and upper gap (which is wider gap usually) we suggest 60 mm wide tapes to use.

Tapes and silicon is not included in cabin kit.

See instruction WP 1:

1- remove outer trims/decoration boards around window or door, need screwdriver

2- add Silicon in designated points (to prevent water to penetrate from those gaps (use UV proof Silicon and transparent color)

3- attach wind/water stopper tapes around the window/door. For sides and bottom can use max 50mm wide tapes, upper horizontal gap needs usually 60mm wide tape.

But if the same 50mm tape covers well also upper gap then can use the same 50mm wide tape everywhere. Just be sure that trim can cover the tape after you re-install trims.

4 – screw all trims/decoration boards back.

About waterproofing the shell we have instructions:

- WP 1 - windows and doors: waterproof taping outside
- WP 1.1 - windows and doors: window and door flashings
- WP 2 - corners: corner waterproofing with Silicon
- WP 3 - corners: corner cover sets

WP 1

